

## Bags and cases for musical instruments

### Produkt 191359 Tanglewood OGBA2 Active Gig Bag 4/4 Cl.

Safety data sheet for bags and cases for musical instruments

Product: Bags and cases for musical instruments

Usage: Musical instrument bags and cases are used to safely transport and store musical instruments to protect them from physical damage, moisture and dirt.

Materials: These bags and suitcases are typically made of materials such as nylon, polyester, leather, wood, plastic, and metal fittings.

#### Risks:

Risk of injury: Sharp edges or protruding parts on the bags or suitcases can lead to cuts.

Risk of breakage: Improper handling can result in damage to the bags or cases and the instrument they contain.

Allergic Reactions: Some materials may cause allergic reactions.

#### Security measures:

Handling: Handle the bags and cases carefully and avoid excessive stress or impact.

Usage: Make sure bags and cases are properly closed to transport the instrument safely.

Disposal: Properly dispose of damaged or no longer functional bags and suitcases.

Allergic Reactions: Avoid contact with materials to which you have allergic reactions.

Storage Notes: Store bags and cases in a dry, safe place, away from direct sunlight and extreme temperatures.

#### First aid measures:

Injuries caused by sharp edges: Clean the wound thoroughly and apply a sterile compress.

Injuries caused by falling suitcases: Secure the area and seek medical attention if necessary.

Manufacturer Gerhard Knauer Großhandel  
Welfenstr. 11 DE 70736 Fellbach  
Phone +49-711-5788750 Email info@gknauer.de