

## Acoustic and electric musical instruments

### Product 215010 Kirkland Classic Mod. 11 white

Safety data sheet for acoustic and electrical instruments

Product: Acoustic and Electrical Instruments

Usage: Acoustic and electric instruments are used to create music. Acoustic instruments include guitars, violins, flutes and pianos, while electric instruments such as electric guitars, keyboards and electric basses produce sounds through electrical amplification.

Materials: These instruments are typically made from a combination of wood, metal, plastic, electronics, and sometimes other materials.

Risks:

Risk of injury: Sharp edges or protruding parts can lead to cuts.

Risk of breakage: Improper handling can result in damage to the instruments and possible injury.

Allergic reactions: Some materials, especially exotic woods or certain varnishes, can cause allergic reactions.

Electrical Danger: Electrical instruments pose a risk of electric shock if the electronic components are handled improperly.

Security measures:

Handling: Handle the instruments carefully and avoid impact or dropping them.

Use: Use the instruments only for their intended purpose and check their condition regularly.

Disposal: Properly dispose of damaged or no longer functional instruments.

Allergic Reactions: Avoid contact with materials to which you have allergic reactions.

Electrical Safety: Ensure all electrical components are properly installed and grounded.

Storage Notes: Store instruments in a dry, safe place, away from direct sunlight and extreme temperatures to avoid damage.

First aid measures:

Injuries caused by sharp edges: Clean the wound thoroughly and apply a sterile compress.

Injuries caused by falling instruments: Secure the instrument and seek medical attention if necessary.

Allergic reactions: Rinse the affected area thoroughly with water and seek medical attention if symptoms are severe.

Electrical injuries: Immediately unplug the electrical instrument and seek medical attention.

Manufacturer Gerhard Knauer Großhandel  
Welfenstr. 11 DE 70736 Fellbach  
Phone +49-711-5788750 Email [info@taikimusic.com](mailto:info@taikimusic.com)