

Harmonicas

Product 666337 Fender Blues Harmonica Deluxe B flat

Safety Data Sheet for Harmonicas
Product: Harmonicas (harmonicas)

Use: Harmonicas are used to play music. They are versatile wind instruments used in various musical styles such as blues, folk, jazz and classical music.

Materials:

Body: plastic, metal (e.g. brass, aluminum), wood
Reeds: metal (e.g. brass, bronze)
Cover plates: metal (e.g. stainless steel), plastic

Risks:

Mechanical danger: Improper use or damaged harmonicas can lead to injuries (e.g. cuts from sharp edges).

Hygienic danger: Sharing harmonicas without proper cleaning can lead to the transmission of diseases.

Allergic Reactions: Some materials may cause allergic reactions in sensitive individuals.

Choking hazard: Small parts such as screws can be swallowed, which is particularly dangerous for children.

Security measures:

Handling: Use the harmonica only according to the manufacturer's instructions and ensure proper use.

Use: Check the harmonica regularly for wear or damage and replace defective harmonicas immediately.

Hygiene: Clean the harmonica regularly and do not share it with other people to avoid the transmission of diseases.

Storage: Store the harmonica in a dry, cool place, away from direct sunlight and extreme temperatures.

First aid measures:

Mechanical Injuries: Treat any injuries and seek medical attention if necessary.

Allergic Reactions: If you experience signs of an allergic reaction, clean the affected area thoroughly with water and seek medical attention if necessary.

Hygienic measures: Seek medical attention if symptoms of illness are due to contamination.

Choking Hazard: Seek medical attention immediately if any part is swallowed.

Manufacturer Fender Musical Instruments GmbH
Heerdter Landstr. 191 DE 40549 Düsseldorf
Phone +49-800-1800721 Email info@fender.com