

## Guitar replacement parts

**Product 673153 AP GS 0050-002 PG-Schrauben Gibson gold**

Safety Data Sheet for Guitar Replacement Parts

**Product:** Spare parts for guitars (e.g. strings, tuners, pickups, potentiometers, buttons)

**Usage:** Guitar replacement parts are used to replace damaged or worn parts on guitars and restore their functionality.

**Materials:** Guitar replacement parts can be made from a variety of materials, including wood, metal, plastic, rubber, and electronics.

**Risks:**

**Risk of injury:** Sharp edges or protruding parts can cause cuts.

**Electrical Danger:** Electronic replacement parts can cause electric shock if handled improperly.

**Allergic Reactions:** Some materials may cause allergic reactions.

**Security measures:**

**Handling:** Handle the spare parts carefully and avoid improper use.

**Usage:** Use only the recommended tools and methods for replacing replacement parts.

**Disposal:** Properly dispose of damaged or no longer functional spare parts.

**Allergic Reactions:** Avoid contact with materials to which you have allergic reactions.

**Storage Notes:** Store replacement parts in a dry, safe place, away from direct sunlight and extreme temperatures.

**First aid measures:**

**Injuries caused by sharp edges:** Clean the wound thoroughly and apply a sterile compress.

**Electrical injuries:** Immediately unplug the electronic replacement part and seek medical attention.

**Allergic reactions:** Rinse the affected area thoroughly with water and seek medical attention if symptoms are severe.

Manufacturer Gerhard Knauer Großhandel  
Welfenstr. 11 DE 70736 Fellbach  
Phone +49-711-5788750 Email [info@gknauer.de](mailto:info@gknauer.de)