Harmonicas

Product 690288 Fender[®] Midnight Blues Harmonica A

Safety Data Sheet for Harmonicas Product: Harmonicas (harmonicas) Use: Harmonicas are used to play music. They are versatile wind instruments used in various musical styles such as blues, folk, jazz and classical music. Materials: Body: plastic, metal (e.g. brass, aluminum), wood Reeds: metal (e.g. brass, bronze) Cover plates: metal (e.g. stainless steel), plastic Risks: Mechanical danger: Improper use or damaged harmonicas can lead to injuries (e.g. cuts from sharp edges). Hygienic danger: Sharing harmonicas without proper cleaning can lead to the transmission of diseases. Allergic Reactions: Some materials may cause allergic reactions in sensitive individuals. Choking hazard: Small parts such as screws can be swallowed, which is particularly dangerous for children. Security measures: Handling: Use the harmonica only according to the manufacturer's instructions and ensure proper use. Use: Check the harmonica regularly for wear or damage and replace defective harmonicas immediately. Hygiene: Clean the harmonica regularly and do not share it with other people to avoid the transmission of diseases. Storage: Store the harmonica in a dry, cool place, away from direct sunlight and extreme temperatures. First aid measures: Mechanical Injuries: Treat any injuries and seek medical attention if necessary. Allergic Reactions: If you experience signs of an allergic reaction, clean the affected area thoroughly with water and seek medical attention if necessary. Hygienic measures: Seek medical attention if symptoms of illness are due to contamination. Choking Hazard: Seek medical attention immediately if any part is swallowed. Manufacturer Fender Musical Instruments GmbH Heerdter Landstr. 191 DE 40549 Düsseldorf Phone +49-800-1800721 Email info@fender.com