

Bags and cases for musical instruments

Produkt 690482 EVH® Wolfgang® Striped Series Gig Bag

Safety data sheet for bags and cases for musical instruments

Product: Bags and cases for musical instruments

Usage: Musical instrument bags and cases are used to safely transport and store musical instruments to protect them from physical damage, moisture and dirt.

Materials: These bags and suitcases are typically made of materials such as nylon, polyester, leather, wood, plastic, and metal fittings.

Risks:

Risk of injury: Sharp edges or protruding parts on the bags or suitcases can lead to cuts.

Risk of breakage: Improper handling can result in damage to the bags or cases and the instrument they contain.

Allergic Reactions: Some materials may cause allergic reactions.

Security measures:

Handling: Handle the bags and cases carefully and avoid excessive stress or impact.

Usage: Make sure bags and cases are properly closed to transport the instrument safely.

Disposal: Properly dispose of damaged or no longer functional bags and suitcases.

Allergic Reactions: Avoid contact with materials to which you have allergic reactions.

Storage Notes: Store bags and cases in a dry, safe place, away from direct sunlight and extreme temperatures.

First aid measures:

Injuries caused by sharp edges: Clean the wound thoroughly and apply a sterile compress.

Injuries caused by falling suitcases: Secure the area and seek medical attention if necessary.

Manufacturer Fender Musical Instruments GmbH
Heerdter Landstr. 191 DE 40549 Düsseldorf
Phone +49-800-1800721 Email info@fender.com