

Guitar replacement parts

Product 745322 Schaller Vintage Tremolo 42mm black chr.

Safety Data Sheet for Guitar Replacement Parts

Product: Spare parts for guitars (e.g. strings, tuners, pickups, potentiometers, buttons)

Usage: Guitar replacement parts are used to replace damaged or worn parts on guitars and restore their functionality.

Materials: Guitar replacement parts can be made from a variety of materials, including wood, metal, plastic, rubber, and electronics.

Risks:

Risk of injury: Sharp edges or protruding parts can cause cuts.

Electrical Danger: Electronic replacement parts can cause electric shock if handled improperly.

Allergic Reactions: Some materials may cause allergic reactions.

Security measures:

Handling: Handle the spare parts carefully and avoid improper use.

Usage: Use only the recommended tools and methods for replacing replacement parts.

Disposal: Properly dispose of damaged or no longer functional spare parts.

Allergic Reactions: Avoid contact with materials to which you have allergic reactions.

Storage Notes: Store replacement parts in a dry, safe place, away from direct sunlight and extreme temperatures.

First aid measures:

Injuries caused by sharp edges: Clean the wound thoroughly and apply a sterile compress.

Electrical injuries: Immediately unplug the electronic replacement part and seek medical attention.

Allergic reactions: Rinse the affected area thoroughly with water and seek medical attention if symptoms are severe.

Manufacturer Schaller GmbH

An der Heide 15 DE 92353 Postbauer-Heng

Phone +49-9180-91023 Email info@schaller.info