

## Guitar replacement parts

### Product 746122 Schaller Speed Knob black chrome (2)

#### Safety Data Sheet for Guitar Replacement Parts

**Product:** Spare parts for guitars (e.g. strings, tuners, pickups, potentiometers, buttons)

**Usage:** Guitar replacement parts are used to replace damaged or worn parts on guitars and restore their functionality.

**Materials:** Guitar replacement parts can be made from a variety of materials, including wood, metal, plastic, rubber, and electronics.

#### Risks:

**Risk of injury:** Sharp edges or protruding parts can cause cuts.

**Electrical Danger:** Electronic replacement parts can cause electric shock if handled improperly.

**Allergic Reactions:** Some materials may cause allergic reactions.

#### Security measures:

**Handling:** Handle the spare parts carefully and avoid improper use.

**Usage:** Use only the recommended tools and methods for replacing replacement parts.

**Disposal:** Properly dispose of damaged or no longer functional spare parts.

**Allergic Reactions:** Avoid contact with materials to which you have allergic reactions.

**Storage Notes:** Store replacement parts in a dry, safe place, away from direct sunlight and extreme temperatures.

#### First aid measures:

**Injuries caused by sharp edges:** Clean the wound thoroughly and apply a sterile compress.

**Electrical injuries:** Immediately unplug the electronic replacement part and seek medical attention.

**Allergic reactions:** Rinse the affected area thoroughly with water and seek medical attention if symptoms are severe.

Manufacturer Schaller GmbH

An der Heide 15 DE 92353 Postbauer-Heng

Phone +49-9180-91023 Email [info@schaller.info](mailto:info@schaller.info)