Music stands and stands for musical instruments Product 774623 K & M 21329 Adapter 25cm M20 schwarz Safety Data Sheet for music stands and stands for musical instruments Usage: Music stands are used to hold sheet music, while musical instrument stands are used to store musical instruments safely. Materials: These stands are typically made of metal, plastic, and sometimes wood. Risks: Risk of injury: Sharp edges or protruding parts can lead to cuts. Danger of tipping: Improper use can cause the stand to tip over and damage the instrument. Allergic Reactions: Some materials may cause allergic reactions. Security measures: Handling: Handle the stands with care and avoid improper use. Usage: Make sure stands are on a flat surface and properly secured. Disposal: Properly dispose of damaged or no longer functional stands. Allergic Reactions: Avoid contact with materials to which you have allergic reactions. Storage Notes: Store stands in a dry, safe location, away from direct sunlight and extreme temperatures. First aid measures: Injuries caused by sharp edges: Clean the wound thoroughly and apply a sterile compress. First aid measures: Injuries caused by sharp edges: Clean the wound thoroughly and apply a sterile compress. Tipping accidents: Secure fallen stands and check the instrument for damage. If you are injured, seek medical attention. Allergic reactions: Rinse the affected area thoroughly with water and seek medical attention if symptoms are severe.

Manufacturer König & Meyer GmbH Postfach 1453 DE 97877 Wertheim Phone +49-9342-8060 Email contact@k-m.de