

Music stands and stands for musical instruments

Product 779925 K & M 23830 Mikrofon-Halteschiene schw.

Safety Data Sheet for music stands and stands for musical instruments

Usage: Music stands are used to hold sheet music, while musical instrument stands are used to store musical instruments safely.

Materials: These stands are typically made of metal, plastic, and sometimes wood.

Risks:

Risk of injury: Sharp edges or protruding parts can lead to cuts.

Danger of tipping: Improper use can cause the stand to tip over and damage the instrument.

Allergic Reactions: Some materials may cause allergic reactions.

Security measures:

Handling: Handle the stands with care and avoid improper use.

Usage: Make sure stands are on a flat surface and properly secured.

Disposal: Properly dispose of damaged or no longer functional stands.

Allergic Reactions: Avoid contact with materials to which you have allergic reactions.

Storage Notes: Store stands in a dry, safe location, away from direct sunlight and extreme temperatures.

First aid measures:

Injuries caused by sharp edges: Clean the wound thoroughly and apply a sterile compress.

First aid measures:

Injuries caused by sharp edges: Clean the wound thoroughly and apply a sterile compress.

Tipping accidents: Secure fallen stands and check the instrument for damage. If you are injured, seek medical attention.

Allergic reactions: Rinse the affected area thoroughly with water and seek medical attention if symptoms are severe.

Manufacturer König & Meyer GmbH
Postfach 1453 DE 97877 Wertheim
Phone +49-9342-8060 Email contact@k-m.de